

to enlarge the corresponding holes in the As with any part of this nature, make sure it fits your mount to 7/16". application before painting or plating. Parts that have been painted, plated, or modified may not be returned.

When installing the mount, start all bolts and mount the compressor before tightening.

A.C.
COMPRESSOR
MOUNT
121R
Big Block Chevy - Short Water Pump

Passenger Side

ALAN GROVE COMPONENTS, INC. 27070 METCALF ROAD LOUISBURG, KS 66053