



NOTE: Some heads have 3/8" bolt holes and some have 7/16". This kit includes both sizes of bolts for these holes.

If your head has 7/16" it will be necessary to enlarge the corresponding holes in the mount to 7/16".

When installing the mount, start all bolts and mount the compressor before tightening.

As with any part of this nature, make sure it fits your application before painting or plating. Parts that have been painted, plated, or modified may not be returned.

A.C. COMPRESSOR MOUNT 122L

Big Block Chevy - Long Water Pump
Driver's Side - Wide Mount

ALAN GROVE COMPONENTS, INC. 27070 METCALF ROAD LOUISBURG, KS 66053