

C2H70 Deco Window Connector JR20 4.75mm Jump Ring

## **Necessary Tools**

- Ergonomic Chain Nose Pliers (2 pairs)
- Bale Making Pliers



## **Helpful Tips**

This technique can be used with many different types of filigree and connectors.

Visit us online for the latest tips, techniques & project ideas:
vintaj.com



Step 1 Hold your connector.



Firmly grip the center of the connector with your bale making pliers, with the back side facing the smaller of the two barrels.

Step 2 Curve your connector.



- A: Bend one end of the connector following the curve of the smaller barrel.
- B: Repeat on the opposite end of the connector.

**Step 3** Finish the bale.



- A: Use your bale making pliers to round out any awkward bends by gently crimping down while following the curve of the bale.
- B: Use your chain nose pliers to line up the holes on each end of the bale.