

R



Microwave Rice Cooker

USER CARE AND INSTRUCTION MANUAL

Thank you for purchasing the **RICARDO** microwave rice cooker. Please read the user manual carefully before using this product.

GUIDE FOR WHITE RICE AND WHITE LONG GRAIN	RICE	SALT (optional)	WATER	SUGGESTED COOKING TIME	YIELD
If using the rice measure included with the rice cooker	1 measure	1/8 tsp	1 1/2 measures	10-12 minutes	1 cup
	2 measures	1/4 tsp	3 measures	12-16 minutes	2 cups
	3 measures	1/2 tsp	4 1/4 measures	15-19 minutes	4 cups
	4 measures	1/2 tsp	5 1/4 measures	18-21 minutes	6 cups
If using conventional 8 oz measuring cups	1 1/2 cups	1/4 tsp	2 1/4 cups	12-16 minutes	2 cups

GUIDE FOR BROWN RICE	RICE	WATER	SUGGESTED COOKING TIME	YIELD
If using the rice measure included with the rice cooker	2 measures	4 measures	25-30 minutes	3 cups
If using conventional 8 oz measuring cups	1 1/2 cups	3 cups	25-30 minutes	3 cups

HELPFUL TIPS


- ::: Use stock or broth instead of water for added flavor.
- ::: Margarine or butter may also be added after cooking.
- ::: Once cooked, mix the rice well with the serving spoon.

If you have any questions regarding this product, please contact our customer service:

- ::: by e-mail: kitchenproducts@ricardocuisine.com
- ::: by phone: 1-866-226-9222

PARTS IDENTIFICATION

Product may vary slightly from diagram.



1. cover
2. locking tabs
3. inner lid
4. locking clamps
5. container
6. rice measure,
¾ cup capacity (170 ml)
7. serving spoon

WARNINGS

- ::: Do not use in the oven, on a stovetop, an open flame or direct heat source. For microwave use only.
- ::: Do not allow unit to boil dry.
- ::: **CAUTION** Be careful when removing from the microwave and use oven mitts as product may be hot. Beware of hot steam when removing cover and use caution when straining hot liquids.
- ::: Do not use abrasive cleaners or scouring pads for cleaning.

KEY TO SUCCESSFUL MICROWAVE COOKING

Cooking times and rice to water proportions may vary depending on the microwave wattage and the type of rice used. The proportions and times below are provided as a guide only and are given for microwaves of 1000 watts and above. Optimize your microwave experience by learning how to adjust the power level of your microwave. For best results, please consult the rice package and refer to the microwave's instruction manual.

INSTRUCTIONS

Before first use, wash all parts in warm soapy water or in the top rack of the dishwasher.

- ::: Using the provided rice measure, fill the measure with rice to the edge and add rice to the container.
- ::: Rinse rice several times to remove excess starch. Drain.
- ::: Add water using the provided rice measure, as per following tables. Wipe dry exterior of the container.
- ::: Place the inner lid and the cover on the container. Close both locking clamps securely over the locking tabs on lid to lock the rice cooker. A "click" should be heard.
- ::: Place the rice cooker in the microwave and cook at high heat following the suggested cooking times.

IMPORTANT

- ::: The rice measure included follows industry standard and is not equal to a standard measuring cup. The included rice measure is equal to ¾ of a standard cup (170 ml).
- ::: Do not cook parboiled rice, instant rice, converted rice, pure wild rice or boxed rice dishes with seasoning packets in this rice cooker.