

HOW TO USE NOSO PATCHES

Add flair or repair

What Are NoSo Patches

NoSo Patches are polyester gear repair patches, perfect for fixing your favorite outdoor apparel. This is great for keeping your beloved apparel out of landfills—which is a benefit for the planet and your wallet.



How to Use NoSo Patches



Prep and clean the affected area. Clean the damaged area—alcohol wipes work best. Remove loose threads or any obstructions.



Crack it and stick it. Crack your NoSo patch and peel away the paper liner. Center the patch over the damaged area and apply pressure. Achieve a nice, smooth fit by starting in the center and moving out to the edges.



Apply heat to make it last. If you're on the go, just sticking a NoSo Patch is good enough. But when you have the opportunity, apply heat to make it permanent. You can use a hairdryer, tumble dry on low for 15 minutes, or (if it's hot enough outside) even use the sunshine. Apply moderate pressure in a circular motion for 30 seconds for the best results.