

# **User instruction manual**

## **HUNTING MASTER**

**AR6K**

**AR6, AR4**

**AR22**

**K550**

### **WARNINGS**

**Not a toy. Adult supervision required. Misuse or careless use may cause serious injury or death. May be dangerous up to 1,000 yards.**

**Read this entire manual before filling, loading or shooting your gun!**

**Fill pressure : 200 bar**

### **IMPORTANT:**

**Note: Your air rifle does not come with open sights. You must mount an optical sight before use. Use a good quality mount for best accuracy and proper alignment.**

**Not a toy. Adult supervision required. Misuse or careless use may cause serious injury or death. May be dangerous up to 1,000 yards.**

**This airgun is intended for use by those 18 years of age or older. 1**

## **Rules of safe shooting**

- **Never point a gun at anyone or anything even if you think the gun is unloaded.**
- **Wear shooting/safety glasses where appropriate and ensure those around you do too.**
- **Always keep your gun on SAFE until you are ready to shoot safely.**
- **Always use a safe backstop in a safe location in case the backstop should fail or any pellets pass through it.**
- **Never load your gun until you are ready to shoot and it is safe to do so.**
- **Never shoot at hard surfaces, water or anything else that may cause a ricochet.**
- **Always ensure a gun is on SAFE and unloaded when receiving a gun or giving a gun to someone else. Many accidents are caused by people handling guns that they thought were unloaded and safe!**
- **Never put a gun away loaded or cocked.**
- **Always be sure of your target and what lies beyond.**
- **Never re-use ammunition.**
- **Ensure you always use the correct caliber ammunition that is suitable for your gun.**
- **Never rely solely on the safety; the most important safety feature is you!**
- **Always treat a gun as if it is loaded and with the respect any loaded gun commands.**
- **Always read and follow the manufacturer's manual and instructions.**
- **Always make sure you understand how to use any gun before using it.**
- **Always keep your finger off the trigger and clear of the triggerguard until you are ready to shoot and it is safe to do so.**
- **Always store the gun in a safe place, unloaded and uncocked, and out of reach of children and unauthorized users.**
- **Always store ammunition separately from the gun.**
- **Always abide by laws and regulations that apply to airguns.**
- **Always use the correct and recommended lubricants, failure to do so may cause injury or damage.**

**Shooting is one of the safest sports in the world, but misuse and careless use of guns can cause serious injury or death**

# Filling the rifle

## AR6, AR4



**Attach the stainless steel fill adapter to the correct fill equipment. Rotate the fill port's protective cover to allow access. Insert the fill adapter into the fill port.**

**Do not use any other type of adapter other than the one supplied with the rifle.**

**Slowly fill the rifle to a MAXIMUM of 200 bar**

## AR6K



**Filling the rifle too fast is unsafe and creates excess heat that may result in a low or inaccurate fill pressure.**

**Do not overfill as this will damage the gun and result in low power. Such damage is not covered under warranty.**

## AR22



**When charging is complete, bleed the excess air using the fill apparatus bleed screw and remove the fill adapter from the rifle.**

**When finished, rotate the protective cover to prevent contamination of the fill port**

## AR22

### Pressure gauge of air cylinder



### Pressure gauge of regulator



## K550



**Uses a fill adapter (included)  
Do not use any other type of  
adapter other than the  
one included with the gun!**

## Loading the rifle

Your rifle uses a rotary magazine,

.177 : 6 rounds, .22 : 6 rounds, .25 : 6 rounds, 10mm deep



Front of mag shown. Insert a rear of pellet into magazine



Do it like above photo

Pellet inserted but, not properly seated

## Inserting magazine to the guns And Removing magazine from the guns

. Safety position and push magazine



## Trigger system



**Single action :**  
**cocking and fire**

**Double action :**  
**fire without cocking**

## Safety

**To engage the safety, push the safety catch lever rearward to the S position. When the safety is engaged, the trigger is locked and the rifle cannot be fired. To disengage the safety and fire the rifle, push the safety lever forward to the F position.**



**S : Safe**

**F : Fire**

## Maintenance tips

1. **Clean your rifle's exterior with a good-quality silicone product.**
2. **Apply the silicone to a lint-free cloth and then wipe down the rifle's exterior.**
3. **Do NOT leave the air filler hole exposed. Always replace the protective cover when not filling the gun with air.**
4. **Do NOT rely solely on the safety to provide guaranteed safety. YOU are the ultimate safety for your gun.**
5. **Do NOT leave pellets loaded in the breech of the rifle. Always remove the magazine from the rifle when you are done shooting.**
6. **Do NOT fill the rifle quickly with air. If it is charged too quickly, it can dislodge the valve from its seat, cause excess heat buildup and give inaccurate fill pressure readings.**
7. **Do NOT overfill the rifle beyond the fill pressure stated on the front of this manual. Overfilling the gun could be dangerous, damage the rifle, deliver substandard performance and cause it to malfunction.**
8. **Do NOT use mineral-based oils or greases.**
9. **Do NOT use petroleum-based oils or greases.**
10. **Occasionally, lightly lubricate the probe o-rings with diver's silicone grease.**

## WARNINGS

**Keep the air rifle on SAFE until you're ready to shoot, then push the safety OFF.**

**Do not inhale dust from lead pellets or put lead pellets in the mouth. Wash hands after handling lead. Lead pellets contain lead, a chemical known to the State of California to cause cancer and birth defects (or other reproductive harm).**

**Use the correct pellet size for your Evanix rifle model. Never reuse pellets.**

**The use of any other kind of ammunition can cause injury to you or damage to your rifle.**

# WARRENTY

## **. One-Year Limited Warranty**

**This product is warranted to the retail consumer for one year from date of retail purchase against defects in material and workmanship and is transferable.**

### **What is covered:**

**Replacement parts and labor. Transportation charges to consumer for repaired product.**

### **What is NOT covered:**

- **Transportation charges to Air Venturi for defective products.**
- **Damages caused by abuse or failure to perform normal maintenance.**
- **Any other expense.**
- **Parts subject to normal wear and tear.**
- **Consequential damages, incidental damages or incidental expenses including damage to property.**

**NOTE: Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.**