## **USG STATUARY HYDROCAL® BRAND**

# GYPSUM CEMENT SOUTHARD, OK

#### **DESCRIPTION**

USG Statuary Hydrocal® Brand Gypsum Cement is a good multi-purpose product for people looking to upgrade from a standard plaster product to one that has a higher degree of hardness and impact resistance. USG Statuary Hydrocal Gypsum Cement is designed for solid and hollow casting and is ideal for giftware and lamp base applications. USG Statuary Hydrocal Gypsum Cement is compatible with numerous color pigments. If information for a specific use is needed, please contact your local USG Sales Representative for further assistance.

## **TYPICAL PHYSICAL PROPERTIES**

% Maximum Expansion	0.42%
Density, Dry (lbs./cu. ft.)	90.0
Density, Wet (lbs./cu.ft.)	110.0
Compressive Strength, Dry (psi)	6000
Compressive Strength, One Hour After Set (psi)	3000
Hand Mix Vicat Set, Target (minutes)	15 - 25
Normal Consistency (lbs. water/100 lbs. product)	31 - 35

**NOTE** The *Typical Physical Properties* in the above table were achieved under controlled laboratory conditions with freshly produced material, results may vary. Other set times may be available; call your USG Sales Representative for more information.

#### **MIXING INSTRUCTIONS**

MIX PREPARATION

Use potable water at temperatures between 70 °F and 100 °F. Because variations in slurry (USG Statuary Hydrocal Gypsum Cement and water mixture) temperature produce variations in set time, it is important to keep both the USG Statuary Hydrocal Gypsum Cement and water in a stable temperature environment prior to use. The higher the temperature of the slurry, the shorter the set time. Conversely, the lower the temperature of the slurry, the longer the set time.

Weigh both the USG Statuary Hydrocal Gypsum Cement and the water prior to use for each mix. The water-to-USG Statuary Hydrocal Gypsum Cement ratio is critical because it governs the strength and the density of the final cast.

SOAKING

Sift or strew USG Statuary Hydrocal Gypsum Cement into the water slowly and evenly. Do not drop large amounts of USG Statuary Hydrocal Gypsum Cement directly into the water as proper soaking of the USG Statuary Hydrocal Gypsum Cement may not occur. USG Statuary Hydrocal Gypsum Cement should be fully dispersed in the water prior to mixing. Small batches require less soaking time than large batches. See USG IG503 *Plaster Mixing Procedures* for specific soaking instructions.

MIXING

Mixing USG Statuary Hydrocal Gypsum Cement slurry is one of the most important steps in producing USG Statuary Hydrocal Gypsum Cement casts with maximum strength, absorption, hardness and other important properties.

Mechanically mixed slurries develop uniform casts with optimal strengths. USG Statuary Hydrocal Gypsum Cement can be mechanically mixed through both batch and continuous processes. Proper blade and bucket dimensions are important for obtaining the best batch mix (see USG IG503 Plaster Mixing Procedures for details).

Longer mixing times result in higher mold strength and shorter set times.



#### **POURING**

To prevent air entrainment and provide a uniform, smooth surface, careful pouring of USG Statuary Hydrocal Gypsum Cement slurry is necessary. Agitation of the filled mold is a further step used to prevent air at or near the mold surface. Whenever possible, USG Statuary Hydrocal Gypsum Cement slurry should be poured carefully in the deepest area so that the slurry flows evenly across the surface of the case mold.

Pouring a large amount of slurry directly on the face of the case mold may result in slight densification of the USG Statuary Hydrocal Gypsum Cement mold at the point where it strikes the surface of the case. This produces a hard spot, giving uneven absorption.

#### **DRYING**

All casts should be dried as quickly as is safely possible after manufacture so that maximum physical properties can develop. Dry to a constant weight.

The best drying rooms or ovens provide 1) uniform and rapid circulation (minimum of 15-30 fps) of air with no "dead spots" having little or no air movement, 2) equal temperatures throughout the entire area, and 3) provisions for exhausting a portion of the air while replacing it with fresh air. High humidity surrounding the drying room or oven inhibits drying efficiency because the air pulled into the room is incapable of picking up much moisture from the molds.

The maximum temperature at which USG Statuary Hydrocal Gypsum Cement molds are safe from calcination is 120 °F. With substantial free water in the mold, a higher drying temperature can be used without difficulty. As drying progresses, the temperature must be reduced to prevent calcination. Before removing molds from the dryer, the temperature should approach that of the area around the dryer to prevent thermal shock.

#### STORAGE AND USE

When properly used, USG Statuary Hydrocal Gypsum Cement is safe to handle and easy to work with. Keep indoors in a dry, stable environment. Do not stack more than two pallets high. Keep from drafts. Rotate stock. Always follow handling and use directions and safety warnings on the package.

## PRODUCT INFORMATION

See usg.com for the most up-to-date product information.

When mixed with water, this material hardens and becomes very hot sometimes quickly. DO NOT attempt to make a cast enclosing any part of the body using this material. Dust from mixing may cause irritation to eyes, skin, nose, throat and upper respiratory tract. Use only in a well-ventilated area, wear a NIOSH/MSHA-approved respirator. Wear eye protection. If eye contact occurs, flush thoroughly with water for 15 minutes. If on skin: Wash with plenty of water. If swallowed and/or irritation persists, call physician, For more information call Product Safety: 800-507-8899 or see the

#### KEEP OUT OF REACH OF CHILDREN.

### TRADEMARKS

The trademarks USG, HYDROCAL, IT'S YOUR WORLD. BUILD IT., the USG logo, the design elements and colors and related marks are trademarks of USG Corporation or

We shall not be liable for incidental or consequential damages, directly or indirectly sustained, nor for any loss caused by application of these goods not in accordance with current printed instruction or for other than the intended use. Our liability is expressly limited to replacement of defective goods. Any claim shall be deemed waived unless made in writing to us within thirty (30) days from date it was or reasonably should have been discovered.

Follow good safety/industrial hygiene practices during installation. Wear appropriate personal protective equipment. Read SDS and literature before specification and installation.

800 USG.4YOU 800 (874.4968) usa.com

Manufactured by United States Gynsum Company 550 West Adams Street Chicago, IL 60661



